


Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



43140-04

①	Klemmflansch	Clamping flange	JP43713
②	Wartungsdeckel	Service lid	JP42798
③	Steuerung	Control unit	
	...25		JP45786
	...35		JP45787
	...55		JP45989
	...75		JP47662
	...100		JP47663
	...200		JP47664
④	Behälter	Tank	JP45945
⑤	Klemmflansch	Clamping flange	JP43713
⑥	Pumpenlüftung	Pump ventilation	JP43732
⑦	Auftriebssicherung	Anti float set	JP43716
⑧	Elast. Verbindung	Elastic connector	JP46009
⑨	Pumpe	Pump	
	25/4 C1		JP47651
	35/4 C1		JP47652
	55/4 C5		JP47653
	75/4 C5		JP47654
	75/4 B6		JP47655
	35/2 B2		JP47656
	55/2 B2		JP47657
	75/2 B5		JP47658
	100/2 B5		JP47659
	200/2 B6		JP47660
⑩	Dichtungssatz	Seal set	JP46074
⑪	Niveauschaltung	Level control	JP47306
⑫	Pumpenfüße	Pump pedestal	JP46075
⑬	Stütze	Support	
	B2		JP47669
	B5		JP47665
	B6		JP47666
	C1		JP47667
	C5		JP47668
⑭	Fußkrümmer	Bend receiver base	JP47661