

Ersatzteile - Spare parts - Pièces de rechange - Reserveonderdelen - Parti di ricambio - Reservedele - Reservdelar
 Varaosat - Części zamienne - Náhradní díly - Alkatrészek - Piese de schimb - Запасные части - 备件



①




②



③



④



⑤



⑥



⑦



⑧



⑨



⑩



⑪

① Gehäuse ADP	Housing ADP	JP47692
② Scharnier	Hinge	JP48310
③ Wippschalter	Switch, 3 positions	JP47783
④ Taster	Button	JP48309
⑤ Klemme RK 2,5-4	Terminal RK 2,5-4	JP48308
⑥ Betriebsstundenzähler	Operation hours counter	JP47672
⑦ Gedruckte Schaltung	PCB	
	AD 4 ExW	JP47724
	AD 8 ExW	JP47724
	AD 23 Ex	JP48491
	AD 25 Ex	JP47723
	AD 46 Ex	JP47725
	AD 610 Ex	JP47727
	AD 910 Ex	JP48314
⑧ Überstromrelais	Overcurrent relay	
	ZE-2,4 1,6-2,4 A	JP47778
	ZE-4 2,4-4 A	JP47779
	ZE-6 4-6 A	JP47780
	ZE-9 6-9 A	JP47781
	ZE-12 9-12 A	JP48312
⑨ Schütz	Contactor	
	DIL EM 10	JP47671
	DIL EM 12-15	JP48311
⑩ Motorschutz	Motor protection	
	4A ETA	JP48490
	8A ETA	JP47683
⑪ Kondensator	Capacitor	
	8 µF	JP46357
	20 µF	JP46016